



WARNING!

1.877.FASTOYS

TRINITY RACING DOES NOT TAKE RESPONSIBILITY FOR DAMAGES THAT MAY OCCUR DURING OPERATION OF YOUR VEHICLE UNDER IMPROPER JET SETTINGS. IT IS THE FINAL RESPONSIBILITY OF THE OWNER/RIDER TO ADJUST JETTING TO SPECIFIC RIDING CONDITIONS AND ELEVATION BEFORE RIDING.

PLEASE FOLLOW ALL OF THESE INSTRUCTIONS CAREFULLY.

YAMAHA YFZ450 POWERFLOW INSTRUCTIONS

PARTS AND INSTALLATION PROCEDURE

1. Remove the airbox. Drill all five rivets on the airbox on the airbox with a 17/64" drill bit and remove the stock air filter holder. Clean the airbox thoroughly.
2. Install the billet adapter from the inside of the airbox with the Stage IV logo at the top of the airbox. Insert the bolts and washers from the carburetor side of the airbox and then secure it with locknuts.
3. Oil your new air filter with K&N air filter oil or another approved paper filter oil.
4. Install the filter onto the billet adapter and make sure the rubber neck of the air filter is completely free of oil. Tighten the filter clamp securely, but do not over tighten and cut into the rubber neck of the filter.
5. Reinstall the air box assemble with lid (if you choose to reinstall the airbox lid) onto the bike. Be sure to tighten and double-check all the nuts and bolts you have installed.
6. Check your ATV's jetting. Depending on your modifications and riding altitude, a jetting change may be required for your ATV to run properly.

THANK YOU FOR YOUR BUSINESS. HAVE A FUN AND SAFE RIDE!